



















ASSEMBLY INSTRUCTION

WD-17022



A  x1	B  x2	C  x1	D  x1	E  x1	F  x2	G1  x1	A1  x2	A2  x2	H 35mm x18 60mm x2
						G2  x1		A3  x2	





ASSEMBLY INSTRUCTION

WD-17022

