

ASSEMBLY INSTRUCTIONS

DESCRIPTION - WOODY BONDVILLA SIDBOARD

0.20 HOURS


APPROXIMATELY ASSEMBLY TIME

2 PERSON ASSEMBLY



CEILING HEIGHT
3 M

REQUIRED ASSEMBLY SPACE



HARDWARE



(S)


Allen Bolt - 6 Pieces

REQUIRED ASSEMBLY TOOL




(A)

Allen Key :- 1 Piece




LEGS FRAME - 2 Set




CARCASE - 1 Piece

















STEP-1





STEP-2



Care & Maintenance



-   ● Do not put hot items directly on furniture surface.
-   ● Do not clean furniture with harsh cleansers or polish.
-   ● Do not place furniture in direct sunlight.
-   ● Do not place furniture near heating or cooling vents.
-   ● Do not write on furniture without a padded barrier to protect the surface.
-   ● Do not place furniture outside. For indoor use only.
-   ● Dust and pick-up spills using a clean, non-colored, lint-free cloth.
-   ● Stains may be removed with mild soap solution and damp cloth.

TIP STRAP FITTING INSTRUCTIONS




STEP:

Make a mark on the wall through the strap



STEP:


Insert screw through washer in wall



NOTE: Wall Fixing are not supplied with this product as different wall materials require different types of fixing device (such as Rawl plugs on brick wall). You must use fixing device suitable for the type of wall you intend to mount this product to. Please ensure that the board of any screw used has a diameter greater than the diameter of the mounting hole on the product and that the fixing is safe and secure before use.

The strap and screw which is to be used on furniture are provided only.

HARDWARE LIST



⚠ WARNING

Young children can be killed when furniture tips over. Place TVs on lower furniture, as far back as possible. Use angle-braces or anchors to secure furniture to wall.