




TIP STRAP FITTING INSTRUCTIONS




STEP : 2  
Make a mark on  
the wall through  
the strap .



Drill a hole in the  
wall and insert the  
rawl plug .



STEP : 3  
Insert screw through  
washer into hole in wall



NOTE: Wall Fixings are not supplied with this product as different wall materials require different types of fixing devices (such as Rawl plugs on brick work) You must use fixing devices suitable for the type of wall you intend to mount this product to. Please ensure that the head of any screw used has a diameter greater than the diameter of the mounting hole on the product and that the fixing is safe and secure before use.

The strap and screw which to fix the strap on to the furniture are provided only.

HARDWARE LIST



2 X  
Screw



2 X  
Washer


ASSEMBLY  
INSTRUCTIONS

DESCRIPTION:- RUMI SIDEBORD  
MB 182609

0.25 HOURS


APPROXIMATE ASSEMBLY TIME

2 PERSON ASSEMBLY




CEILING HEIGHT  
3 M

REQUIRED ASSEMBLY SPACE



HARDWARE




H1 6 Pieces





H2 6 Pieces

REQUIRED ASSEMBLY TOOLS




T1 1 Piece



LEGS :- 2 PIECES


CARCASE :- 1 PIECES

## STEP - 1




NOTE:- Each Leg is numbered.  
Please match according to respective  
markings.

















## STEP - 2



## FINAL PRODUCT



## Care & Maintenance

-   ☐ Do not put hot items directly on furniture surface.
-   ☐ Do not clean furniture with harsh cleansers or polish.
-   ☐ Do not place furniture in direct sunlight.
-   ☐ Do not place furniture near heating or cooling vents.
-   ☐ Do not write on furniture without a padded barrier to protect the surface.
-   ☐ Do not place furniture outside. For indoor use only.
-   ☐ Dust and pick-up spills using a clean, non-colored, lint-free cloth.
-   ☐ Stains may be removed with mild soap solution and damp cloth.