

















Care & Maintenance

- 

☐ Do not put hot items directly on furniture surface.
- 

☐ Do not clean furniture with harsh cleansers or polish.
- 

☐ Do not place furniture in direct sunlight.
- 

☐ Do not place furniture near heating or cooling vents.
- 

☐ Do not write on furniture without a padded barrier to protect the surface.
- 

☐ Do not place furniture outside. For indoor use only.
- 

☐ Dust and pick-up spills using a clean, non-colored, lint-free cloth.
- 

☐ Stains may be removed with mild soap solution and damp cloth.


ASSEMBLY INSTRUCTIONS

DESCRIPTION:- LIVE EDGE CRISS CROSS DINING TABLE MB-186100

0.30 HOURS

APPROXIMATE ASSEMBLY TIME


2 PERSON ASSEMBLY



REQUIRED ASSEMBLY SPACE






CEILING HEIGHT
2 M




HARDWARE

REQUIRED ASSEMBLY TOOLS




TOP :- 1 Piece




LEG FRAME:- 2 Piece

Step:- 1


NOTE:- Each component is numbered.
Please match according to respective
markings.




Step:- 2



Step:- 3



Step:- 4



FINAL PRODUCT

